


PARTS LIST

1. TAP
2. BONNET
3. FIBER WASHER
4. SPINDLE
5. ANTI-VANDAL KIT
6. PROTECTIVE COVER
7. TAP FLANGE
8. LEVER HANDLE
9. HOT-COLD DISC



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.