


PARTS LIST

1. WALL MIXER SET BREEACH
2. WALL MIXER BODY
3. 35MM CARTRIDGE
4. LOCKNUT DOME
5. GRUB SCEW M4X5
6. O-RING 38X2.5
7. MIXER HANDLE
8. BACKPLATE
9. O-RING 33X2.0
10. SCREW M4X35
11. GRUB SCREW CAP
12. OUTLET 200MM



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.