


PARTS LIST

1. WALL SPOUT FLANGE
2. WALL SPOUT TAIL
3. SPOUT SWIVEL
4. SPOUT
5. AERATOR ADAPTOR
6. AERATOR RETAINER
7. O-RING 11X2.0MM
8. NYLON WASHER
9. O-RING 43X2.0MM
10. WASHER
11. AERATOR
12. GRUB SCREW



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.