


## PARTS LIST

1. WASHER 44MM
2. SCREW CAP
3. GRUB SCREW M5X5
4. BACK PLATE
5. OUTLET ADAPTER
6. GRUB SCREW M5X5
7. O-RING 14X2.5
8. O-RING 22X2.5
9. RETAINER
10. WASHER
11. AERATOR
12. HANDLE
13. SPOUT



## MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.