


PARTS LIST

1. 180MM WALL OUTLET
2. DRESS PLATE
3. RETAINER
4. AERATOR 7LT/MIN
5. MAX FLOW AERATOR
6. GASKET



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.