PARTS LIST 6 5 1. BACK PLATE 3 2. 180MM OUTLET 3. WASHER 4. HANDLE 5. SCREW CAP 6. GRUB SCREW M5X5 7. AERATOR 7LT/MIN 2 8. MAX FLOW AERATOR 9. RETAINER 10. GASKET 10 8

MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
 Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.