

MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.

PACKAGING INCLUDES

- I x Mixer body
- I x Dress plate
- I x Handle
- I x Spout
- I x Free flow aerator (bath installation)
- I x Installation kit
- I x Installation instructions
- I x Warranty card