PARTS LIST

- I. MIXER BODY
- 2. GRUB SCREW M4X6MM
- 3. GRUB SCREW M4X4MM
- 4. CARTRIDGE SEAT EXTENSION
- O-RING 20X2.75MM
- 6. 25MM CARTRIDGE
- 7. MIXER HANDLE
- 8. SCREW CAP
- 9. MIXER LOCKNUT
- 10. O-RING 22X2,0MM
- II. MIXER DOME
- 12. AERATOR RETAINER
- 13. AERATOR
- 14. O-RING 16X1.5MM
- 15. MIXER SWIVEL TAIL
- 16. SWIVEL PLATE
- 17. RUBBER WASHER
- 18. WASHER
- 19. TAIL LOCK RING
- 20. NYLON BEARING
- 21. SWIVEL STOP SCREW
- 22. O-RING 22X1.75MM
- 23. HOSE SWIVEL ADAPTER
- 24. FLEXIBLE HOSE 450MM HOT
- 25. FLEXIBLE HOSE 450MM COLD
- 26. SWIVEL SPACER
- 27. LOCKNUT GASKET
- 28. MIXER TAIL LOCKNUT

MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.

