
PARTS LIST

- I. SPOUT 280MM
- 2. BACKPLATE
- 3. G1/2" SPOUT ADAPTER
- 4. GRUB SCREW M4X5MM
- O-RING 50X3.0MM
- 6. O-RING 13X2.6MM
- 7. O-RING 21X1.9MM
- 8. AERATOR



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface.
 Any damage caused in this way will not be covered by warranty.

PACKAGING INCLUDES

- I xWall Basin Outlet 280mm
- I x Installation kit
- I x Installation instructions
- I x Warranty card