


PARTS LIST

1. 20MM WASHER
2. 44MM WASHER
3. SCREW CAP
4. GRUB SCREW M5X5
5. DIVERTER HANDLE
6. DRESS PLATE
7. MIXER HANDLE
8. RUBBER PLUG



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.