1.0hr

APPROXIMATE ASSEMBLY TIME

2 PERSON ASSEMBLY



FLOOR AREA 2M x 2M




REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS






PHILLIPS SCREWDRIVER



Flat Head screwdriver



DO NOT USE POWER DRILL



Important

Please read these instructions carefully before use and keep for future reference.

- This product is intended for domestic use only and is not designed for commercial use.
- Do not assemble/use this item if any components are missing or damaged. Please contact the retailer straight away.
- DO NOT attempt to modify your item as this will void your warranty. Please call the retailer for required parts.
- Assembly to be carried out by a competent adult only.
- During assembly children should be kept away from the product due to possible risk of injury.

Please refer to separate Warranty Certificate for full warranty details and information.

Tips before you start:

- Please check that all parts are present before you start the assembly of your furniture.
 Please do not start to build your item if any parts are damaged as this may void your warranty. Please contact the retailer immediately so they can advise what you should do.
- For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.

Assembly Tips


- 1. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
- 2. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- 3. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- 4. During assembly please take care not to over-tighten any fittings, as this may damage the product.
- 5. Always place the product on a flat, steady and stable surface.
- 6. Do not stand on the product. Do not use the product as a stepladder.
- 7. This product is intended for indoor, household use only as it is non industrial product.
- 8. Use of power tools is NOT recommended for assembling this product.
- 9. Due to the painted finish of this product, when first opening the carton and assembling, the smell of paint may be noticeable. If there is any smell of paint it will dissipate over a short period of time. The paint is non-toxic and contains no lead. Please contact the retailer you purchased this item from if you have any concerns.
- 10. Please use caution and care when lifting the product to avoid personal injury and/or damage.

Care and Maintenance of your Furniture

- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean. Never use harsh chemicals or strong detergents as this could damage the finish of your product.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Avoid placing sharp objects on the surface as this may scratch the surface. It is recommended to use trivets or coasters under flowerpots, vases, cups etc to avoid damage to your item.
- Please do not place hot/cold items (eg. Hot drinks) directly on to the surface.


Tips before you start:

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK




When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

Quickfit head should be in the centre of the cam lock when the two panels are joined.


Cam lock should be inserted before quickfit.





Turn cam lock clockwise to tighten.

HARDWARE LIST



Pin

Fasterner

Screw

Screw


PARTS LIST

Screw


Handle


Handle screw

1 1PC	2 2PCS	3 2PCS	4 1PC
5 1PC	6 1PC	7 1PC	8 1PC
9 1PC	10 1PC	11 1PC	12 2PCS




STEP 1






Insert the towel rail (3) and assemble the hanger rail (2) to the left side panel (1) with the longest screws(A).

STEP 2





2.Assemble the storage to the right side panel (7) with wood dowel(E), bolt (J), nut (I) and longest wood screws (A).















STEP 3

(E).


Ensure the 2nd person is holding the panels (8)(9) to support them until this step is completed, this will C x 2 avoid damage to your item. (8) Ē D x 2 E x 10 F x 9 ∦E ∮ 1. Assemble the partition panel (8) to the shelf panel (9) J x 2 with bolt (J), nut (I)and wood dowel (E). 2. Assemble the bottom stretcher (12&18) to the bottom shelf (11) with shortest bolts (F) and wood dowel Ix2




1. Assemble the middle shelf (9) and bottom shelf (11) to right side panel (7) with cam bolt (C), cam lock (D), bolt (J), nut (I) and wood dowel (E).



STEP 6





Assemble the caster with lock (K) and caster (L) to the left side frame (1) & right side frame (7) with wrench (M).

C


STEP 7




Ensure the 2nd person is holding the panel (14) to support them until this step is completed, this will avoid damage to your item.


To ensure the backing board slides into the correct position you may find it easier to move/lift the shelf (9) to assist the backing board sitting in the slots provided. Ensure that it is properly installed before you attach the countertop.

- 1.Stand unit upright. Insert the back panel (13).
- 2. Assemble the top panel (14) with wood dowel (E), cam bolt (C) and cam lock (D), please pay attention to assemble the cam lock on both side panels firstly.
- 3. Lift panel (9) to fix the cam locks between top panel (14) and division board (8)



STEP 8








1.Insert the screw (N) to fix the slat and top panel.

STEP 9

just lock the upper and lower screws



Do not overtighten screws in this step, the final hinge adjustments are part of step 12 where you can tighten the screws one at a time to ensure your door is hung int he right position. Only use the screws for the upper and lower holes in this step.



Do not overtighten the handle screws.















W x 8

1Attached (O) on upper corner of the inside door tighten with screw (Q).

- 2. Attached handle (R) on the door tighten with screw (S).
- 3. Attached hinge (P) on the door tighten with screw (W).

STEP 10






NOTF:

Only place the upper and lower screws and do not overtighten until your doors are hung correctly and in the right position. Refer to Step 12 for final adjustments and tightening of the screws once doors are correctly hung.

- 1. Attached hinge (P) on the door tighten with screw (W).
- 2. Insert metal support (T) to panel (1) (7)&(8), then put the panel (17) on it.

STEP 11







∢€€€€€\$ V x 4

- 1.Insert the plastic fastener (U) to the back panel as shown position with screw (V)
- 2.to make sure the whole product is stable.

STEP 12

Attention: If the doors may shift or sag after assembly, please adjust the hinges according to below instruction.






Vertically adjustment

Slightly adjust the screws position on side panels.

When the doors are flush, lock the middle screws on hinges.





Horizontally adjustment

Slightly adjust the screws position on doors.

When the doors are flush, lock the middle screws on hinges.



Warranty Certificate

Congratulations! You have made an excellent choice of this quality product. Our commitment to quality also includes our service. Should you, contrary to expectations, experience defects due to manufacturing faults, Meubilai r Direct Imports will provide you with a warranty against defects as follows:

Warrantv

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred

by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket, tax invoice or receipt as the best proof of purchase, and as proof of date on which the purchase was made.

Normal Wear and Tear

This warranty does not cover normal wear and tear to the products or parts.

Exclusions

This warranty does not cover:

- Any defects caused by an accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification, loss of parts, tampering or attempted repair by a person not authorized by the distributor.
- Any product that has not been installed, operated or maintained in accordance with the manufacturers' operating instructions provided with the product.
- Any product that has been used for purposes other than domestic use.
- \square Any damage caused by improper power input or improper cable connection.

MEUBILAIR DIRECT IMPORTS PTY LTD

Customer Service

Email: cs@meubilair.com.au

Address: Unit 4, 4-5 Lambridge Place, Penrith, NSW, 2750

Opening Hou rs 9:00 am -4:00pm (Mon -Fri)

When making a return, please ensure the product is properly packaged, so as to ensure that no damage occurs to the product during transit.

Please provide the original or a copy of the proof of purchase. Also please make sure you have included an explanation of the problem.

Please note that the costs of making a warranty claim, including any return postage, will be covered by the supplier identified above.

Please note upon receiving your warranty claim, the supplier will send, via the post or email, a repair and refurbished goods or parts notice. Please provide your email address and advise the supplier, if you wish to obtain a repair and refurbished goods or parts notice via email.

AFTER SALES SUPPORT

EMAIL: cs@meubilair.com.au Product code: 102077-05





Warranty Certificate

/	
	PRODUCT NAME: Kitchen 2 Door Island Solid Wood Counter Top
	BRAND NAME:
	PRODUCT CODE: 102077-05
/	
/	NAME
	ADDRESS
	EMAIL DAYTIME TEL NO
	DATE OF PURCHASE
	SERIAL NUMBER
\	

We recommend that you attach a photocopy of your receipt, showing the date of purchase, to this Warranty certificate and keep for your reference.

In the event of a product fault, please email the Customer Service team. Please ensure that you include the product details (as shown on the card) at hand so that we are able to respond as quickly and efficiently as possible.

Meubilair Direct Imports PTY LTD

Customer Service

Email: cs@meubilair.com.au

Address: Unit 4, 4-5 Lambridge Place, Penrith, NSW, 2750

Opening Hours 9:00 am -4:00pm (Mon -Fri)

AFTER SALES SUPPORT

EMAIL : cs@meubilair.com.au Product code: 102077-05

