



Cable exits the back 35mm from bottom of rail.  
When ordering please specify left or right side as viewed from the FRONT

