



Cable exits the back 35mm from bottom of rail.
When ordering please specify left or right side as
viewed from the FRONT

