



Cable exits the back 35mm from bottom of rail.
 When ordering please specify left or right side as
 viewed from the FRONT

