


ASSEMBLY INSTRUCTION

Dining Chair



Customer Service Before Return:

If part is missing or damaged, or you need help with assembly,
please do not hesitate to contact us.





SELLER CONTACT INFORMATION:
cpcontacts@163.com

Before Assembly

IMPORTANT NOTE:

- Make sure all parts and hardware are included and free of obvious Defect before disposing of any packaging
- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- DO NOT tighten all screws and bolts until completely assembled.
- Assembly will require one people.

PART LIST

<p>A</p> 	<p>B</p> 	<p>C</p> 	<p>D</p> 		
<p>1PC</p>	<p>1PC</p>	<p>1PC</p>	<p>1PC</p>		


HAPDWAPE LIST

[illegible]


NOTED:

1.Do not fully tighten all bolts until all parts are in place.Failure to follow these instructions may cause the bolt to misalign during assembly.



Step 1




Step 2



Step 3



Step 4



Step 5

