


ASSEMBLY INSTRUCTION ENDTABLE



Customer Service Before Return:

If part is missing or damaged, or you need help with assembly,
please do not hesitate to contact us.




SELLER CONTACT INFORMATION:

cpcontacts@163.com






ASSEMBLY INSTRUCTION


- 1.Extra Screws of A/B/C/D are provided in case of any screws missing in the boxes.
- 2.Please take the time to identify and count all parts as well as the hardware to this product.

PART LIST

		
① x1PC	② x3PCS	③ x1PC

HARDWARE

				
1/4*12mm	1/4*30mm			Allen Key
Ax6PCS	Bx3PCS	Cx9PCS	Dx9PCS	Ex1PC



Noted:

1. It is recommended that this item should be assembled by two adults.
2. Assemble this item on a soft surface, such as cardboard or carpet, to protect finish.

For product assistance and warranty information, please contact US before return this product:

Customer Service: cpcontacts@163.com

Please provide us with following Information, so that It will be easier to resolve your problem smoothly.


1、 Order ID:

2、 Pictures of Your Items Damage or Parts Missing:

Thank You for Purchasing Our Furniture, It's an Honor to Be in Your Home!


NOTED Pls do not tighten all bolts until the products is assembled completely.

Step 1:



Ax6PCS	Cx6PCS	Dx6PCS
--------	--------	--------

Step 2:



Bx3PCS	Cx3PCS	Dx3PCS
--------	--------	--------

Step 3:

