


ASSEMBLY INSTRUCTION

Dining Chair



Customer Service Before Return:

If part is missing or damaged, or you need help with assembly, please do not hesitate to contact us.





SELLER CONTACT INFORMATION:
cpcontacts@163.com

Before Assembly

IMPORTANT NOTE:

- Make sure all parts and hardware are included and free of obvious Defect before disposing of any packaging
- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- DO NOT tighten all screws and bolts until completely assembled.
- Assembly will require one people.

PART LIST

A	B	C	D
			
1PC	1PC	1PC	1PC



HAPDWAPE LIST

E	F	G	H				
 M6×55	 M6×40	 M6×16	 M6				
4+1PC	1+1PC	4+1PC	1PC				

NOTED:

1. Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolt to misalign during assembly.


Step 1




When crossing legs C and D, make sure two tabs are facing inward.





Failure to follow this will cause issues during Step 3




Step 2



Step 3



Step 4



Step 5

