


Model : MG 7783

Product Size : (W) 1405mm x (D) 770mm x (H) 815mm

Thank you for purchasing this product. Before starting assembly we suggest you spend a short time reading through this leaflet, then follow the simple step by step guide.
One person is needed to assemble this product.



TOP TIPS BEFORE YOU START !

IMPORTANT- READ CAREFULLY- RETAIN FOR FUTURE REFERENCE

1. Please check that all parts & hardware are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, Please identify all the parts required for that step.
3. We recommend that where possible, all items are assembled near to the area in which they will be placed in use, to Avoid moving the product unnecessarily once assembled.
4. For the protection of your furniture, particularly items of high gloss finish, we recommend that the product is placed on a Protected surface during assembly to prevent any damage.
5. During assembly please take care not to over-tighten any fittings, as this may damage the product.

CARE AND MAINTENANCE OF YOUR FURNITURE


- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not place hot items (e.g hot drinks) directly on the wood surface.
- Please do not drag or pull your furniture.

Guide To Assembly



Model : MG 7783

Tools Required For Assembly

FlatHead
Screwdriver



Phillips Screwdriver



DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT. USE OF POWER TOOLS WILL INVALIDATE ANY CLAIM AND MAY DAMAGE THIS PRODUCT MAKING IT UNSAFE.




Approximately 1 hour 30min




2 People required for assembly





Rubber Hammer



Measure




Lay out parts carefully and ensure all required parts are present.



Part List

Model : MG 7783

Carton 1 of 2			Carton 2 of 2		
No.	Part Name	Pcs	No.	Part Name	Pcs
03	Desk Bottom Panel (Middle)	1	01	Desk Bottom Panel (Left)	1
10	Desk Top Panel Surface	1	02	Desk Bottom Panel (Right)	1
11	Desk Tie Beam	1	04	Side Panel (Left)	1
12	Screen Deck Side Panel	2	05	Side Panel (Inner Left)	1
13	Screen Deck Side Panel	2	06	Side Panel (Right)	1
14	Screen Deck Panel (Top)	1	07	Side Panel (Inner Right)	1
			08	Left Shelf Panel (Front)	1
			09	Right Shelf Panel (Front)	1
			15	Shelf Panel Panel	1
			Assembly Instructions + Fitting List		





Fitting List

Model : MG 7783

Carton 2 of 2

Fitting List

No.	Part Name		Pcs
A	Cam Stud (small)		40
B	Cam		40
C	M8 x 25mm Wood Dowel		49
D	Metal Shelf Support		4
E	Felt Pads (45mm x 45mm)		8

Caution

There are many small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit. As an extra precaution, screw cover caps should be permanently fixed in position. (Where applicable)

USEFUL HINTS & TIPS

Two people will be required to assemble this unit

Please keep this assembly instruction for future reference

Guide To Assembly

Model : MG 7783

1



A x 8



B x 40





C x 49



D x 4

WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Guide To Assembly

Model : MG 7783


2




3



4



5




Guide To Assembly

Model : MG 7783

6




A x 12




WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE



7





8




Guide To Assembly


Model : MG 7783


9  D x 8



10  A x 2





11  A x 10



WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Guide To Assembly

Model : MG 7783


12



13





A x 4



WHEN FITTING CAMS


ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Guide To Assembly

Model : MG 7783

14



15





Guide To Assembly

Model : MG 7783


16  A x 4

WHEN FITTING CAMS

ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE



17



18

