

Thank you for purchasing the Dining Chair. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. The following page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.


Care Information

Periodically check and re-tighten any fasteners. Dust weekly using a soft, clean cloth. Do not use harsh abrasives, chemicals or polishes containing silicone. Avoid direct sunlight as this may cause the timber to change colour. It is important to remove moist substances immediately.







Always carefully lift furniture when moving it around the home and never drag.

Use floor protectors on the bottom of furniture (like tables and chairs) to minimise damage to floor coverings.

Use coasters, place mats, tablecloths and table runners to protect furniture surfaces from heat and stains



Hardware (Supplied)

A x 4  M6x35 mm	B x 4  M6x20 mm	C x 4  M6x45 mm	D x 4  M6x16 mm
F x 4 	H x 1  5 mm		




30
min




This assembly requires
one person

Tools Required (Not Supplied)



DO NOT USE A
POWERDRILL
TO COMPLETE ASSEMBLY




Parts




Step 1





Step 2




Fix the connection with screw A




Step 3




Step 4





Attach the scratch-resistant pad



Tighten the connection area with screws C.






Step 5





Fix the backrest (1) with screws D.

Step 6



Step 7



Step 8

