











Before installation, please ensure that the purchased **SIZE** matches the product you received.






## **Top tips before assembly**

1. Check that all parts are present before starting the assembly.
2. For ease and speed of assembly, it is recommended that all parts and hardware required for that step are identified before commencing assembly.
3. Place the product on a soft and padded surface to do the assembly to prevent damage to the finishes and surfaces of the product.
4. During assembly, do not over-tighten any fittings as this may damage the product.

|                                                                                       |                                                                                        |                                                                                       |                                                                                       |                                                                                         |                                                                                         |                                                                                          |
|---------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
|  Ax30  |  Bx30  |  Cx34 |  Dx46 |  Ex4   |  Fx4  |  Gx4   |
|  Hx20 |  Ix24 |  Jx8 |  Kx2 |  Lx12 |  Mx6 |  Nx40 |
|  Ox4  |  Px4  |  Qx4 |  Rx1 |  Sx26 |  Tx2 |  Ux2  |
|  Vx3  |  Wx1  |                                                                                       |                                                                                       |                                                                                         |                                                                                         |                                                                                          |




1





x 2

2




X 4


3




4




5



6




7




x 2


8




9




10




11



12



13



14

