PARTS LIST

1. SPOUT
2. GASKET
3. AERATOR
4. AERATOR RETAINER
5. T-PIECE
6. TAP
7. LOCKNUT PLASTIC
8. NYLON WASHER
9. OUTLET TAIL
10. O-RING 16X2.0MM
11. TAP BODY
12. BASIN NUT
13. BODY WASHER
14. CONNECTOR
15. T-PIECE LOCKNUT
16. 94MM CARTRIDGE
17. TAP FLANGE
18. LEVER HANDLE
19. HOT-COLD DISC
20. BONNET
21. FIBER WASHER
22. ANTI-VANDAL HANDLE KIT



MAINTENANCE AND CARE:

- All surfaces should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.