


ASSEMBLY INSTRUCTION MANUAL

MODEL NO:
HOVER1800



Note:
Fully Assembled

IMPORTANT:

Please read through the instructions carefully before assembly and keep them for future reference.



CHILDREN HAVE DIED FROM FURNITURE TIPOVER.

- NEVER allow children to stand, climb or hang on drawers, doors or shelves.
- ALWAYS secure your television with an anchor device or mount the television on a wall (anchor device not included).

For a complete range of bracket options please visit:
www.tauris.com.au/collections/brackets



Congratulations on your purchase of a new Tauris furniture item.

To increase the longevity of your item, please follow these assembly instructions to save you time, make assembly easier and prevent possible damage to your new unit.

PLEASE NOTE:

- Correct assembly is your responsibility.
- We suggest the use of hand tools only to tighten screws and fittings, as power tools can strip threads if over-tightened.
- When moving this furniture item, always carry the unit. Dragging or sliding the unit could damage the unit and the floor surface.
- It is important to assemble the unit on a soft surface like carpet to prevent damage. If you don't have carpet, place a blanket down before starting.

CUSTOMER SERVICE:

Missing or Faulty Parts:

Please recheck the instructions and packaging to ensure the parts are missing before contacting the store you purchased the item from.

The store will need the following information:

- Copy of purchase slip or receipt.
- Model number of the unit purchased.
- Description or part number of the missing or faulty part.
- Quantity of parts needed.

If for whatever reason you cannot contact the store, please contact Tauris directly at www.tauris.com.au

Product of RVM Australia Pty Ltd


13 Merino Entrance
Cockburn Central
Western Australia 6164
PH: 1300 883 109



PANELS & PARTS LIST:




Please check you have all parts listed before you begin.

<u>CARTON 1</u>		
Part #	Description	Qty
1	Bracket	X1
2	TV Unit	X1



HARDWARE LIST:

Please check you have all parts listed before you begin.

PACK 1			
A	Wall plug		X8
B	Screw Ø5 x 60mm		X8
C	Screw Ø4 x 16mm		X4

All installation environments are different, you may not have all the necessary hardware for your situation. Please consult a professional when considering which hardware is correct for your situation.

Tools you will need (Not Included):


- Drill
- 6mm Drill bit
- 3mm Drill bit
- Phillips head screwdriver
- Stud finder (for gyprock walls)
- Spirit level

IMPORTANT INFORMATION:

- Max weight: 20kgs.
- We recommend a professional installs this product.
- Be sure to refer to toppling furniture regulations when securing this unit.
- **This wall mounted cabinet is for the storage of components only and is NOT intended to have a TV placed/stored on it.**

STEP 1:

Decide on the height you would like the top of your unit to be at. Measure 177mm down to mark your first hole location. Place the bracket over the hole with the spirit level on top to find the right angle for the bracket. Then mark the remaining holes with a pencil. Remove the bracket and drill the holes with an appropriate drill bit.



STEP 2:




(B) x 8

OPTION 1 - FOR BRICK WALL



(A) x 8

BRICK WALL NOTE:
Please fix screws into Bricks not Mortar




STEP 2:

OPTION 2 - FOR STUD WALL


 (B) x 8

STUD WALL SAFETY NOTE:

The mounting board has fixing holes in place for a standard stud wall. Please use a stud finder to ensure that you are fixing into the studs.




STEP 3:



STEP 4:

LIFTING CABINET ON TO THE WALL




SAFETY NOTE:

This step should be performed by 2 people to prevent injury.

STEP 5:




Ⓢ x4



SAFETY NOTE:

For the safety of others you must ensure that this cabinet is secured to the wall mount with the provided screws.

STEP 6:



STEP 7:

Well done on completing the assembly of your new Tauris TV unit.

Please share how it looks in your space and tag us on:



@Taurisav




@Tauris

Our complete range can be found at
www.tauris.com.au




ADJUSTING DRAWER FRONTS:

- If the drawer front panel is NOT level after being assembled it can be adjusted.



- Loosen the screws on the runners either side of the drawer, then you can move the drawer slide to adjust the drawer front.
- Once you are happy with the position, you can then tighten the screws to secure.



SURFACE CARE INSTRUCTIONS

A little care and attention will extend the life and look of your furniture. Take care when using materials that might spill, be sharp or abrasive on the surface of your furniture.

NORMAL CLEANING:

For normal cleaning use a soft, dry, clean cloth. In the case of spills/stains use warm water.



GLASS CLEANING:

You may use normal glass cleaning products on all standard glass. Use a soft cloth to remove light dust and fingerprints.



VINYL CLEANING:

DO NOT use solvent-based cleaners or any abrasive materials. Only use a slightly damp, soft, clean cloth on this surface. Do not scrub.



FROSTED GLASS CLEANING:

DO NOT use glass cleaner or solvent-based cleaners on the surface of the glass that has a frosted finish.



CAUTION:

DO NOT expose to direct sunlight or extreme temperature. This will result in irreparable damage and discolouration.

WARRANTY POLICY

1. Nothing in this warranty affects the consumer's rights under the Australian Consumer Law. The benefits to the consumer under this warranty are in the addition to the rights and remedies of the Buyer under any consumer guarantees. The Australian Consumer Law requires that we confirm that:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality.

2. Subject to Clause 1, the Seller warrants that TAURIS branded products will be free of manufacturing defects and will perform to the Seller's specifications subject to the following clauses.
3. The benefit of this 12 Month Warranty extends only to the Owner of the property in which the products manufactured or supplied by the Seller are installed and used by the owner for the duration of the Warranty period.
4. If within the Warranty period a manufacturing defect is discovered in the product, or the product fails to perform to the Seller's specifications as a result of some defect in the material or workmanship, then the Seller will replace or repair the goods under Warranty or refund the purchase price paid by the Owner. Except if the failure is a major failure.
5. The Warranty does not apply to a product that:
- a) Has failed due to excessive wear.
 - b) Has been misused or neglected.

WARRANTY POLICY

- c) Has been damaged accidentally or by acts of God including fire and flood.
 - d) Has been used or operated contrary to the operating or maintenance instructions.
 - e) Has been damaged in transit from the Seller's store to the Owner, either by the Owner or a third party authorised to act for the Owner.
 - f) Was correctly assembled or installed.
6. In order to make a claim under the Warranty, the Owner must provide proof of purchase in all cases.
7. The Seller will examine any return products and if the Seller determines that there is an apparent defect through no fault of the owner, the Seller will:
- a) Make a note of the Owner's contact details, including the Owners telephone number which the Owner can be contacted during business hours, postal address and email address.
 - b) Make note of the defect/s reported by the Owner.
 - c) Take back the defective goods from the Owner and determine within reasonable time through dialogue with the Owner whether the goods are defective.
 - d) Advise the Owner within a reasonable time frame whether the goods are defective.
 - e) If the seller accepts the return of the product, the seller must arrange to have:
 - i) The product repaired or,
 - ii) Replace the damaged or faulty product or,
 - iii) Refund the purchase price
8. The Seller will not accept any returned product which has not been returned strictly in accordance with this warranty.

WARRANTY POLICY

9. For the purpose of this warranty:

- a) Australian Consumer Law means the law set out in Schedule 2 of Competition and Consumer Act 2010 (Cth).
- b) Consumer means purchaser of the goods.
- c) Consumer means a Consumer as that term is set out in Section 3 of the Australian Consumer Law.
- d) Consumer Guarantees mean the guarantees under the Australian Consumer Law.
- e) Implied terms mean guarantees, conditions, warranties, or other terms implied by an Australian Commonwealth, State or Territory laws, (excluding the Australian Consumer Law) or the law of any other jurisdiction.
- f) Owner has the meaning set out in Clause 3.
- g) Warranty means this Warranty.
- h) Product means the Product/s bought by the Owner from the Seller that fall under this warranty.
- i) Warranty Period means:

Furniture: 12 Months Limited Warranty.

Homewares: 12 Months Limited Warranty.

TV mounts: 12 Months Limited Warranty.

Speaker stands: 12 Months Limited Warranty.