



Installation Instructions For Compression Sofa



Do not use knives or sharp objects during unpacking




1. Remove the carton packaging and unroll the rolled sofa the floor




2. Open the roll package, unfold and smooth;



3. Use a box opener to open the box and avoid using sharp tools and knives that may scratch the fabric



4. The compression sofa is opened and placed for 72 hours, waiting for the compression sponge to fully rebound



This picture is for reference only, the actual item may not be the same.



WARM ROOM

20–25°C speeds foam recovery



Warm air = faster expansion



GIVE SPACE

Leave ~30 cm around sofa



Allow airflow on all sides



FLUFF & PAT

Knead and shake cushions



Loosen foam to draw in air



LIGHT STEAM

Use gentle moving steam



Keep steam moving — do not soak



NO PRESSURE

Avoid sitting 24–48 hours



No sitting or heavy objects



WAIT

Full size in 36–72 hours



Normal full expansion time