


BREACH SET-UP


- Ensure that seats in the Breach are in good condition and are free of foreign objects.
- The recommended installation range for the breach are as shown:
- Reseat if required.






Firmly screw Spindle into the Breach.

DO NOT OVERTIGHTEN






3


Fit O-Ring to the groove in the rear of the Flange.

Firmly fasten Flange onto the Spindle.



Fit Handle Hub to Spindle and fasten with the Grub Screw using the Allen Key provided. Screw the Handle Pin into the Handle Hub

4





recommended 50-500

maximum hot water temperature 75 degrees