

ASSEMBLY INSTRUCTION














Attach CL and CR to the left and right sides of the base frame.














STEP 2 Assemble the components together as shown В Use B screws for fixing ø15X10mm


Assemble the componets as shown in the diagram.





Use A,B and Dscrews to secure the connections.














Assemble each component according to the positions shown in the diagram.

Use D,E screws for fixing









STEP 5 С Assemble all components together as shown, use screws for fixing. G С x 16


M3.5x12mm


Assemble each component according to the positions shown in the diagram.




Use A,B and E screws to secure the connections. Different positions may require different screws, so please check carefully before installation.










Assemble each component according to the positions shown in the diagram.




Use A,B and E screws to secure the connections. Different positions may require different screws,so please check carefully before installtion.









Notes:

- · Please follow the steps in order for assembly.
- \cdot Ensure that all screws are tightened properly to ensure the stability of the furniture.
- · If you encounter any problems during assembly, please check whether the parts are used correctly and whether the installation steps are followed properly.