

BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208

1.5 HR

APPROXIMATE ASSEMBLY TIME




**2 PERSON
ASSEMBLY**

**FLOOR AREA
2.5M X 2.0M**




REQUIRED ASSEMBLY SPACE


REQUIRED ASSEMBLY TOOLS



POZI SCREWDRIVER



HAMMER




MEASURING TAPE



DRILL

ASSEMBLED DIMENSIONS



BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208

Important :

Please read these instructions carefully before use and keep for future reference.

- This product is intended for domestic use only and is not designed for commercial use.
- DO NOT assembly / use this item if any components are missing or damaged. Please contact the retailer straight away.
- DO NOT attempt to modify your item as this will void your warranty. Please call the retailer for required parts.
- Assembly to be carried out by a competent adult only.
- During assembly children should be kept away from the product due to possible risk of injury.

Please refer to separate Warranty Certificate for full warranty details and information.

Tips before you start :

- Please check that all parts are present before you start the assembly of your furniture. Please do not start to build your item if any parts are damaged as this may void your warranty. Please contact the retailer immediately so they can advise what you should do.
- For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.

BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208

Tips before you start :

1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you Identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people (as Indicated on page 1) to assemble your product safely.
4. We recommend that, where possible, all Items are assembled near to the area In which they will be placed in use, to avoid moving the product unnecessary once assembled.
5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product.
7. Always place the product on a flat, steady and stable surface.
8. Do not stand on the product. Do not use the product as a stepladder.
9. This product is intended for indoor, household use only as it is non industrial product.

Care and Maintenance of your Furniture




- ☒ Please periodically check all fittings and re-tighten as necessary.
- ☒ To clean your Item, please use a damp cloth and wipe clean.
- ☒ Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- ☒ Please do not place hot item (e.g. hot drinks) directly on to the wood surface.
- ☒ Please do not drag or pull your furniture.

BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208



Tips before you start :

QUICKFIT



Tighten quickfit until shoulder is flush with panel . Do not overtighten or undertighten.


CAM LOCK



When fitting cam lock , ensure starting position is correct before you insert connecting quickfit.

Quickfit head should be in the center of the cam lock when the two panels are joined .

Cam lock should be inserted before quickfit





Turn cam lock clockwise to tighten.

BAYVILLE 4 DRAWER CHEST


ITEM CODE : TVS 208

DRAWER INSTALLATION GUIDE

- Before you insert the drawers into the frame, please ensure that the ball bearing sliders (on the assembled unit) have been placed to the front of the main unit. If the bearings are in the middle of the slider it will be difficult to install the drawers correctly.



- Insert the drawer into the assembled frame as show below. Keep each side of the drawer straight and aligned correctly to the sliders on the assembled frame.




- Gently start to push the drawer into position, the drawer sliders should start to connect with the sliders on the assembled frame. Once connected apply even pressure to each side and gently push the drawer into place.
- The ball bearings should catch the drawer sliders, once they do you may find that you need to apply more pressure, this is perfectly normal as long as you are keeping the drawers straight, push the drawers 100% of the way in. Finally slide drawer in and out a few times to ensure the ball bearings are running smoothly in the slider. Installation is complete.
- At any stage throughout the install process you feel like the drawers are not evenly sliding into the assembled rame, please remove the drawers before they start to attach to the bearing slider and start the install steps again.

BAYVILLE 4 DRAWER CHEST


ITEM CODE : TVS 208

NOTE:



CAUTION


When removing the drawer, be careful to tip up the safety release tab on the left side, and tip it down on the right side to remove the drawer from the body as shown.



BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208

PART LIST:


















NO.	PART NAME	QTY	8	DRAWER (FRONT)	3
1	MIDDLE BOARD (LEFT)	1	9	DRAWER (FRONT)	1
2	SLATS	3	10	DRAWER SIDE PANEL (LEFT)	4
3	BACK SLATS	1	11	DRAWER SIDE PANEL (RIGHT)	4
4	MIDDLE BOARD (RIGHT)	1	12	DRAWER BOTTOM	4
5	BACK PANEL	2	13	DRAWER SLATS	4
6	BOTTOM PANEL	1	14	DRAWER BACK PANEL	4
7	TOP PANEL	1			

BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208

HARDAWRE LIST

A x50  C/B SCREW M3.5 x 12mm	B x16  C/B SCREW M3.5 x 20mm	C x16  C/B SCREW M3.5 x 38mm	D x4  C/B SCREW M4 x 45mm
E x16  SCREW M10 x 12mm	F x 32  DOWEL Ø6 x 25mm	G x28  CAM BOLT	H x28  CAM NUT
I x4  HANDLE	J x2  CAM BOLT LEG	K1 x4 PAIR  14" FULL EXTENSION SLIDE	K2 x4 PAIR  14" FULL EXTENSION SLIDE
L x4  LEG	M x16  BACK PANEL CONNECTOR	N x2  L-BRACKET	

Tips before you start :


- Please check that all parts are present before you start the assembly of your furniture. Please do not start to build your item if any parts are damaged as this may void your warranty. Please contact the retailer immediately so they can advise what you should do.
- For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.

BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208


STEP 1

Insert the Dowel (F) into the designated hole as shown.



STEP 2

Lock the hardware (G) in the designated holes as shown. Panels 1 & 4 Fix the hardware (J) first, then specify the hole position, and then lock the hardware (G) in the hole position of the hardware




BAYVILLE 4 DRAWER CHEST


ITEM CODE : TVS 208

STEP 3

Pull out the (K) as in the illustration, then push the lever to reveal and remove the first component.



Attach drawer glide casing (K1) to panels 1 and 4 using A screw as shown. Ensure the runner lines up with the holes shown on the diagram for correct placement






BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208


STEP 4

As shown in the picture, the bottom of No. 1 board faces upwards. Align the LEG (L) and screw (E) with the marked holes on the base plate and tighten.





STEP 5

As shown in the picture, 10, 11, 14 panels are fixed with screws (C) and tightened. Align the designated hole on No.13 panel with the hardware on No.14 panel, insert the CAM NUT(H) into the designated hole 180° and tighten it.



x4

Note: Its important not to over-tighten screws on the drawer sides until all sides are aligned and the drawer base is inserted. Always keep drawer flat in this step so the groove for the base will align correctly.




BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208

STEP 6


Put panel 12 into slots 10 and 11 as shown in the picture.



x4

STEP 7

As shown in the figure, align the panels 10, 11, 13 with the designated holes on the panel 8 & 9, insert and fix them, and then use the cam nut (H) to tighten at 180° to the designated holes.





x3

BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208


STEP 6

As shown in the picture, fix the HANDLE(I) on the 9, 10 panel with screws.



STEP 7

Secure the first part of the full extension rail (K2) to the panels 10 and 11 of the two drawers with screws (A) as shown. Ensure that the correct holes are being used as per the diagram




BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208


STEP 8

As shown in the picture, align the left holes of the No. 2 and No. 3 panels with the hardware of the No. 1 panels, then put the CAM NUT (H) 180° into the designated holes and tighten.



STEP 9

As shown in the picture, align the right holes of the No. 2 and No. 3 panels with the hardware of the No. 4 panels, then put the CAM NUT (H) 180° into the designated holes and tighten.




BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208


STEP 10

As shown in the picture, insert the rear plate NO.5 into the slotted position




STEP 11

Align the alignment pins on the bottom of panels 1 and 4 with the designated holes on the top of panel 6 as shown, and assemble with screws (D).



**2 PERSON
ASSEMBLY**

Note: Always use atleast 2
adults to stand the item upright



BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208


STEP 12

As shown in the picture, insert the rear plate No. 5A into the slotted position



**2 PERSON
ASSEMBLY**




Note: Always use atleast 2
adults to stand the item upright



STEP 13

Align the holes on the bottom of No. 7 panel with the dowels on the top of No. 1 and No. 4 panels as shown in the picture, then put the cam nuts (H) into the designated holes and tighten them at 180°.

Note: Please always ensure
cams are correctly locked to
secure and support your item.
Refer to camlock guidelines at
the beginning of this manual for
further information




**2 PERSON
ASSEMBLY**

BAYVILLE 4 DRAWER CHEST



ITEM CODE : TVS 208

STEP 14

Insert the rear panel connector (M) into the slot on the edge of the rear panel as shown and secure with the screw (B).






Note: It is important to correctly attach the back ply stoppers as this will help support and stabilise your item



STEP 15

As shown in the picture, fix the L-BRACKET (N) to the bottom of the left and right sides of No. 7 panel with screws (A).

Note: Refer to the wall hanging guidelines for further information




BAYVILLE 4 DRAWER CHEST


ITEM CODE : TVS 208

STEP 16

As shown in the picture, pull out all the slide rails, align with the first drawer, and push it in..





A




- PUSH THE ROLLER OF M1 TO THE FRONT SIDE OF THE BODY.

B



- ALIGN L2 ON LEFT & RIGHT TO L11 AT THE CORRECT POSITION.

C



- PUSH IN LEFT & RIGHT SIDE OF THE DRAWER INTO THE BODY SIMULTANEOUSLY.
- WHEN THE DRAWER IS PUSHED IN HALF WAY, THE STOPPER ON M2 WILL BE ENGAGED INTO M1. THIS WILL CAUSE THE PUSHING A BIT TIGHT. [PULL OUT THE DRAWER A LITTLE BIT AND SLOWLY PUSH IN THE DRAWER AGAIN TO CHECK WHETHER THE DRAWER IS STUCK I THE DRAWER GLIDE IS INSTALLED CORRECTLY.]
- DO NOT PUSH IN THE DRAWER IF THE DRAWER IS STUCK OR CANNOT BE PUSHED IN SMOOTHLY. TAKE OUT THE DRAWER AND REPEAT STEP 1 & 2.

BAYVILLE 4 DRAWER CHEST

ITEM CODE : TVS 208

ASSEMBLY IS COMPLETE




WARNING

Serious or fatal crushing can occur from furniture tip over. To help prevent tip over :

- Install all tip over restraints provided with your product.
- Place heaviest item inside the lower doors.
- Do not sit TV's or other heavy objects on top of this product,
- Never allow children to climb or hang on drawers, doors, shelves.
- Never open more than one door at a time.

Use a tip over restraints may only reduce, but will not eliminate, the risk of tip over.



Bracket Fixing

The horizontal arms of the brackets are to be secured to the underside of shelf so that it is out of sight when the cabinet is installed into position.


After assembling the unit place it against the wall where it will be permanently positioned. Working from inside the cabinet place the bracket through the pre-cut hole in the rear wall of the cabinet as shown in diagram.

Use a pencil to mark through the screw hole in the bracket, where the bracket has to be attached to the wall.

- Move the cabinet away from the wall and secure the bracket to the wall at the marked position using a wall anchor suited to your wall surface.

With the wall brackets in position, move the cabinet back to the wall allowing the horizontal arm of the bracket to enter into the cabinet through the pre-cut holes in the back wall of the cabinet.

Then using the screw supplied, secure the horizontal arm of the brackets to the underside of the shelf.



WARNING:

ENSURE THAT WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY

To avoid any serious injury, this product has been supplied with a wall strap to prevent toppling.

We strongly recommend that this product is permanently fixed to the wall or other suitable surface.

Please seek professional advice if you are in doubt of what fixing should be used. Wall fixings can be purchased from your local hardware store.

Wall Mounting & Fixing Guide

NOTE: Supplied wall plugs are only suitable for use in masonry walls.

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



Tips & Tricks


Make sure that the hardware used is suitable for supporting your unit.

Please consult a qualified tradesperson if unsure.

- ✓ If you are unsure, please select a larger screw and wall plug.
- ✓ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ✓ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ✓ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


Types Of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to



6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.



Warranty Certificate

Congratulations! You have made an excellent choice of this quality product. Our commitment to quality also includes our service. Should you, contrary to expectations, experience defects due to manufacturing faults, **Meubilair Direct Imports** will provide you with a warranty against defects as follows:

Warranty

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket, tax invoice or receipt as the best proof of purchase, and as proof of date on which the purchase was made.

Normal Wear and Tear

This warranty does not cover normal wear and tear to the products or parts.

Exclusions

This warranty does not cover:

- Any defects caused by an accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification, loss of parts, tampering or attempted repair by a person not authorized by the distributor.
- Any product that has not been installed, operated or maintained in accordance with the manufacturers' operating instructions provided with the product.
- Any product that has been used for purposes other than domestic use.
- Any damage caused by improper power input or improper cable connection.

MEUBILAIR DIRECT IMPORTS PTY LTD

Customer Service

Email: cs@meubilair.com.au

Address: Unit 4, 16 Hickeys Road, Penrith, NSW, 2750

Opening hours: 9am to 4pm (Monday – Friday)

Contact Number: (02) 4701 5363

When making a return, please ensure the product is properly packaged, so as to ensure that no damage occurs to the product during transit. Please provide the original or a copy of the proof of purchase. Also please make sure you have included an explanation of the problem. Please note that the costs of making a warranty claim, including any return postage, will be covered by the supplier identified above. Please note upon receiving your warranty claim, the supplier will send, via the post or email, a repair and refurbished goods or parts notice. Please provide your email address and advise the supplier, if you wish to obtain a repair and refurbished goods or parts notice via email.

AFTER SALES SUPPORT

EMAIL : cs@meubilair.com.au

Product code: TVS208





Warranty Certificate

PRODUCT NAME: Bayville 4 drawer chest

BRAND NAME: _____

PRODUCT CODE: TVS208

NAME _____

ADDRESS _____

EMAIL _____

DAYTIME TEL NO _____

DATE OF PURCHASE _____

SERIAL NUMBER _____

We recommend that you attach a photocopy of your receipt, showing the date of purchase, to this Warranty certificate and **keep for your reference.**

In the event of a product fault, please email the Customer Service team. Please ensure that you include the product details (as shown on the card) at hand so that we are able to respond as quickly and efficiently as possible.

MEUBILAIR DIRECT IMPORTS PTY LTD

Customer Service

Email: cs@meubilair.com.au

Address: Unit 4, 16 Hickeys Road, Penrith, NSW, 2750

Opening hours: 9am to 4pm (Monday – Friday)

Contact Number: (02) 4701 5363

AFTER SALES SUPPORT

EMAIL : cs@meubilair.com.au

Product code: TVS208

