ITEM CODE: 8315-WHT

45 MINS

APPROXIMATE ASSEMBLY TIME



FLOOR AREA 2.5M X 2.0M



REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS




POZI SCREWDRIVER



MEASURING TAPE



ASSEMBLED DIMENSIONS



ITEM CODE: 8315-WHT

Important:

Please read these instructions carefully before use and keep for future reference.

- This product is intended for domestic use only and is not designed for commercial use.
- DO NOT assembly / use this item if any components are missing or damaged. Please contact the retailer straight away.
- DO NOT attempt to modify your item as this will void your warranty. Please call the retailer for required parts.
- Assembly to be carried out by a competent adult only.
- During assembly children should be kept away from the product due to possible risk of injury.

Please refer to separate Warranty Certificate for full warranty details and information.

Tips before you start:

- Please check that all parts are present before you start the assembly of your furniture.
 Please do not start to build your item if any parts are damaged as this may void your warranty. Please contact the retailer immediately so they can advise what you should do.
- For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.

ITEM CODE: 8315-WHT

Assembly Tips:

- 1. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assembly your product safely.
- 2. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- 3. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- 4. During assembly please take care not to over-tighten any fittings, as this may damage the product.
- 5. Always place the product on a flat, steady and stable surface.
- 6. Do not stand on the product. Do not use the product as a stepladder.
- 7. This product is intended for indoor, household use only as it is non industrial product.
- 8. Use of power tools is NOT recommended for assembling this product as over-tightening may occur and damage the product.
- 9. Due to the laminated finish of this item and the materials used to construct it, when first opening the carton and assembling a slight smell may be noticeable. This will dissipate over a short period of time. Please contact the retailer you purchased this item from if you have any concerns.
- 10. Please use caution and care when lifting the product to avoid personal injury and / or damage.


Care and Maintenance of your Furniture

- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean. Never use harsh chemicals or strong detergents as this could damage the finish of your product.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not place hot / cold item (e.g. hot drinks) directly on to the surface.
- Do not pull or drag your item. Ensure its evenly supported and lifted while moving it.
- Avoid placing sharp objects on the surface as this may scratch the surface. It is recommended to use trivets or coasters under flowerpots, vases and cups etc to avoid damage to your item.

ITEM CODE: 8315-WHT


Tips before you start:

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

Quickfit head should be in the centre of the cam lock when the two panels are joined.


Cam lock should be inserted before quickfit.



Turn camlock clockwise to tighten.

ITEM CODE: 8315-WHT

PART LIST:



NO.	PART NAME	QTY
1	SIDE PANEL (LEFT)	1
2	SIDE PANEL (RIGHT)	1
3	TOP PANEL	1
4	BOTTOM PANEL	1
5	SHELF PANEL	1


NO.	PART NAME	QTY
6	BOTTOM SUPPORT RAIL	1
7	FRONT PANEL	1
8	DOOR PANEL	1
9	BACK PANEL	2


ITEM CODE: 8315-WHT


HARDWARE LIST



























NOTE: Before you begin assembly please ensure you have separated the hinges to give you part #F1 and #F2.


ITEM CODE: 8315-WHT


STEP 1


Insert dowel (C) into panels (1,2,4,5&6) as shown.
















ITEM CODE: 8315-WHT


STEP 2

Take all panels (1, 2, 3 & 7), using a phillips head screw driver CAM PINS (D) as shown.











ITEM CODE: 8315-WHT

STEP 3


Attach hinges plate (F2) to panel (2) using screw (B) as shown.


Note: The door can be hung on either the left or right hand side. Before you attach the hinge plates please decide

which way you need the door open to suit your individual needs.

Note:The hinges can either be hung on the left or the right side Option A=install hinges on the left Option B=install hinges on the right

Option A G











STEP 4

Attach panels (1 & 2) to panels (4, 5 & 6) using CAM LOCKS (E) as shown.

TIP: Make sure on panel 4 the cams are all facing downwards, this also allows the backing board to line up properly.










ITEM CODE: 8315-WHT


STEP 5

Attach panel (7) to panels (1, 2 & 4) using CAM LOCKS (E) as shown. Then attach plastic leg stud (H) below panels (1 & 2) as shown.



STEP 6

Slot back panel (9) to frame.





ITEM CODE: 8315-WHT

STEP 7

Attach top panel (3) to body frame. Fasten into place using cam locks (E) as shown.

Note: Please always ensure cam's are correctly locked to secure and support your item. Refer to Camlock guidelines at the beginning of this manual for further information.








STEP 8

Attach hinges (F1) to door panel (8) using screw (A) as shown.







ITEM CODE: 8315-WHT

Hinge Installation Guideline





Image shows underside of hinge

STEP 1 - The hinge will arrive connected to the hinge plate.

Take note of the placement of this hinge, this is how it needs to be assembled when you align the door with the hinge plate during building process. (circle)



STEP 2 - Take a part the hinges as shown in the Instructions so that you end up with the door hinge and hinge plate.




Image shows underside of hinge. You can see the middle pin is locked into its position. (circle)

STEP 3 - During installation, when the step requires you to attach the door to the hinge plate on the product please ensure the hinge slides over the hinge plate so the middle pin (circle) slides into the designed slot and locks the hinge in place.

It may be hard to tell if it is in place correctly due to the door being in the way. You could try and gently pull the hinge off the plate. If its locked in it wont move freely.





Image shows underside of hinge. You can see the middle pin clearly. (circle)



STEP 4 - Once you are confident the middle pin is locked into position you can use the screw provided to join the door hinge and the hinge plate together and start the alignment process.

Please refer to the instruction for guidelines on how to adjust the hinges so that your doors align nicely.






Image shows underside of hinge. You can see the middle pin is not locked into its position. (circle)



As per the image below the door hinge should sit nice and flat onto the hinge plate. If its raised (as shown below) then it hasn't correctly locked into position.




ITEM CODE: 8315-WHT

STEP 9

Attach the handle (G) to door panel (8) as shown. Then attach the door panel (8) to side panel (2) as shown.






NOTE:

Before you complete Step 8, its best to tighten the "hinge plates" on panel 2 to ensure they are pushed in as far as they can, so when the door is attached they wont come loose. To successfully do this, please place your hand on the outside of the panel 2 so that you can push your hand inward against the panel as you screw in the hinge plate. Please make sure the screw grabs the side panel the entire way. It can take abit of pressure to successfully do this. You should notice that the hinge plate on these panel 2 will then sit flash with the panels and there should be no gaps between the plate and the side panel.

ITEM CODE: 8315-WHT

HOW TO ADJUST YOUR HINGES AND ALIGN THE DOORS



Follow the adjustments and make sure the middle pin is correctly installed as per previous instructions. If the middle pin isn't correctly installed then this adjustment will not work correctly.

If you tighten/loosen this screw it will adjust the doors to the left/right.


This step usually takes small adjustments and then closing doors to see if the gaps have evened out. Sometimes just half a turn of the screw can make a big impact to the gap.

The hinges are correctly installed and in position once you have a nice straight gap down the sides of the cupboard between the door and the side of the cupboard cavity.


ITEM CODE: 8315-WHT




This adjustment is used if your doors have a big gap at the top or the bottom, or if one door sits straight but is lower than the other door.




Please loosen the screw to adjust the door.




STEP 2
Adjust the door



After adjust, tighten the screw.




This adjustment is used if your doors are TOO CLOSE to the main cavity. You can loosen the screw and then move the door hinge closer or further out depending on the outcome you want to achieve



STEP 1
Please loosen the screw to adjust the door.



STEP 2
Adjust the door.




STEP 3
After adjust, tighten the screw.


ITEM CODE: 8315-WHT

STEP 10

Attach backply stopper (J) to panel (9) as shown using screw 15mm (A) as shown.

Note: It is really important to attach the backply stoppers correctly as this will help with the overall structure and stability of the item.









ASSEMBLY IS COMPLETE




WARNING

Serious or fatal crushing can occur from furniture tip over. To help prevent tip over:

- Install all tip over restraints provided with your product,
 Place heavlest Item Inside the lower doors.
 Do not sit TV's or other heavy objects on top of this product.
 Never allow children to climb or hang on drawers, doors, shelves.
- . Never open more than one door at a time

Use a tip over restraints may only reduce, but will not eliminate, the risk of tip over.





WARNING:

ENSURE THAT WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY

To avoid any serious injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Wall fixing hardware is not supplied as different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing should be use. Wall fixings can be purchased from your local hardware store.



Warranty Certificate

Congratulations! You have made an excellent choice of this quality product. Our commitment to quality also includes our service. Should you, contrary to expectations, experience defects due to manufacturing faults, **Meubilair Direct Imports** will provide you with a warranty against defects as follows:

Warranty

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion. The benefits conferred

by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and

Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket, tax invoice or receipt as the best proof of purchase, and as proof of date on which the purchase was made.

Normal Wear and Tear

This warranty does not cover normal wear and tear to the products or parts.

Exclusions

This warranty does not cover:

- Any defects caused by an accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorize
 dmodification, loss of parts, tampering or attempted repair by a person not authorized by the distributor.
- Any product that has not been installed, operated or maintained in accordance with the manufacturers' operating
 instructions provided with the product.
- Any product that has been used for purposes other than domestic use.
- Any damage caused by improper power input or improper cable connection.

MEUBILAIR DIRECT IMPORTS PTY LTD

Customer Service

Email: cs@meubilair.com.au

Address: Unit 4, 16 Hickeys Lane, Penrith, NSW, 2750

Opening Hours 9:00 am - 4:00pm (Mon-Fri)

When making a return, please ensure the product is properly packaged, so as to ensure that no damage occurs to the product during transit.

Please provide the original or a copy of the proof of purchase. Also please make sure you have included an explanation of the problem.

Please note that the costs of making a warranty claim, including any return postage, will be covered by the supplier identified above.

Please note upon receiving your warranty claim, the supplier will send, via the post or email, a repair and refurbished goods or parts notice.

Please provide your email address and advise the supplier, if you wish to obtain a repair and refurbished goods or parts notice via email.

AFTER SALES SUPPORT

EMAIL: cs@meubilair.com.au Product code: 8315-WHT 05/2023





Warranty Certificate

PRODUCT NAME	HAMPTON SHELF 1 DOOR BEDSIDE TABLE	
BRAND NAME		
PRODUCT CODE	8315-WHT	
NAME		
ADDRESS		

DAYTIME TEL NO

SERIAL NUMBER

DATE OF PURCHASE

EMAIL

We recommend that you attach a photocopy of your receipt, showing the date of purchase, to this Warranty certificate and **keep for your reference.**

In the event of a product fault, please email the Customer Service team. Please ensure that you include the product details (as shown on the card) at hand so that we are able to respond as quickly and efficiently as possible.

MEUBILAIR DIRECT IMPORTS PTY LTD

Customer Service

Email: cs@meubilair.com.au

Address: Unit 4, 16 Hickeys Lane, Penrith, NSW, 2750

Opening Hours 9:00 am - 4:00pm (Mon-Fri)

Phone Number: +61 2 47015363

AFTER SALES SUPPORT

YEAR WARRANTY

05/2023

Product code: 8315-WHT