


# Buffet 4 Doors

2.0 hr

APPROXIMATE ASSEMBLY TIME

2 PERSON ASSEMBLY





FLOOR AREA  
2M x 2M




REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS



PHILLIPS SCREWDRIVER

FLAT HEAD SCREWDRIVER



# Buffet 4 Doors

## Tips before you start:


1. Please check that all parts are present before you start the assembly of your furniture.
2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
6. During assembly please take care not to over-tighten any fittings, as this may damage the product.
7. Always place the product on a flat, steady and stable surface.
8. Do not stand on the product. Do not use the product as a stepladder.
9. This product is intended for indoor, household use only as it is a non-industrial product.
10. Please use caution and care when lifting the product to avoid personal injury and/or product damage.

## Care and Maintenance of your Furniture

- ☒ Please periodically check all fittings and re-tighten as necessary.
- ☒ To clean your item, please use a damp cloth and wipe clean.
- ☒ Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- ☒ Please do not place hot items (eg. hot drinks) directly on to the surface.
- ☒ Please do not drag and pull your furniture.


# Buffet 4 Doors

## QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


## CAM LOCK



When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

Quickfit head should be in the centre of the cam lock when the two panels are joined.


**Cam lock should be inserted before quickfit.**



Turn cam lock clockwise to tighten.

# Buffet 4 Doors

## HARDWARE LIST



10 x A  
Quickfit  
Screw




10 x B  
Cam Lock



20 x C  
Wooden  
Dowel




76 x D  
Screw




10 x E  
Bolt




1 x F  
Allen Key



4 x G  
Hinge




4 x H  
Catch




4 x H1  
Drawer  
Opener




4 x I  
Washer



4 x J  
Bolt



12 x K  
Bolt




16 x L  
Wedge




1 x M  
Foot



2 x N  
Bolt



4 x O  
Hinge



2 x P  
Wall  
Bracket




2 x Q  
Wall Plug



2 x R  
Screw




















2 x S  
Screw



16 x T  
Shelf  
Support

# Buffet 4 Doors



## PARTS LIST

									
1	1 PC		2	1 PC					
									
3	1 PC	4	1 PC	5	1 PC	6	1 PC	7	1 PC
									
8	2 PCS	9	2 PCS	10	4 PCS	11	1 PC	12	2 PCS
									
13	2 PCS	14	1 PC	15	1 PC	16	1 PC	17	1 PC

# Buffet 4 Doors


## STEP 1

Insert quickfit screws (A) and wooden dowels (C) into part 1, as shown.



## STEP 2

Fix wall brackets (P) to part 1 using screws (S), as shown.



# Buffet 4 Doors

## STEP 3

Fix drawer openers (H1) to part 1 using screws (D), as shown.

Insert catches (H) into drawer openers (H1), as shown.




D x 8



H x 4



H1 x 4



# Buffet 4 Doors

## STEP 4


Insert cam locks (B) into parts 3, 4, 5, 6 and 7, as shown.

Fix parts 3, 4, 5, 6 and 7 to part 1, as shown.

Turn cam locks clockwise to tighten.



B x 10




# Buffet 4 Doors

## STEP 5


Insert wooden dowels (C) into parts 3, 4, 5, 6 and 7, as shown.

Insert parts 8 into grooves of parts 1, 3, 4, 5 and 7, as shown.

Insert parts 9 into grooves of parts 1, 5, 6 and 7, as shown.



C x 10



# Buffet 4 Doors

## STEP 6


Fix part 2 to parts 3, 4, 5, 6 and 7 using bolts (E) and allen key (F), as shown.



E x 10



F x 1



# Buffet 4 Doors

## STEP 7


Fix parts 12 to parts 13 using allen key (F) and bolts (J), as shown.



F x 1






J x 4



# Buffet 4 Doors

## STEP 8

Fix parts 12 and 13 to part 2 using allen key (F) and bolts (K), as shown.







# Buffet 4 Doors

## STEP 9

Fix part 11 to part 2 using allen key (F) and bolts (N), as shown.


Insert foot (M) into part 11 by turning clockwise, as shown.



# Buffet 4 Doors

## STEP 10


Secure the parts 8 and 9 with wedges (L) and screws (D), as shown.



D x 16



L x 16



# Buffet 4 Doors

## STEP 11

For extra stability, you must fix your buffet to the wall using the additional hardwares (Q and R), as shown.

Screws (R) are fixed through wall bracket and wall plugs (Q) and into the wall.


**Should you choose not to affix the product to the wall, serious injury may be caused if the product tips over.**



Q x 2





R x 2



# Buffet 4 Doors

## STEP 12


Insert shelf supports (T) into parts 3, 4, 5, 6 and 7, as shown.



# Buffet 4 Doors

## STEP 13

Insert parts 10 into assembled unit. as shown.



# Buffet 4 Doors

## STEP 14

Fix hinges (G) to parts 14 and 17 using screws (D), as shown.

Fix hinges (O) to parts 15 and 16 using screws (D), as shown.

Fix washers (I) to parts 14, 15, 16 and 17 using screws (D), as shown.



D x 20




G x 4



I x 4



O x 4





# Buffet 4 Doors

## STEP 15

Fix parts 14, 15, 16 and 17 to assembled unit through hinges by using screws (D), as shown.




D x 32




### HINGE ADJUSTMENT GUIDE

It may be necessary to adjust the hinges so that the doors align. Use the instructions below as a guide.



To adjust the door **laterally** adjust the screw as shown by turning clockwise or anti-clockwise.




To adjust the door **vertically** loosen the screw as shown and move up and down as needed.



To adjust the **gap** from the door to the main frame turn the screw clockwise or anti-clockwise as needed.

# Buffet 4 Doors

## STEP 16



Your Buffet 4 Doors is ready for use.

**Maximum recommended weight is 25kg on top and 5kg each shelf.**

# Buffet 4 Doors

## WALL FIXING GUIDE

**NOTE: Supplied wall plugs are only suitable for use in masonry walls.**

If you have any doubts about using the correct plug for your wall, please seek professional advice. Failure of the product due to using incorrect fixings is the responsibility of the installer.



### IMPORTANT:

When drilling into walls, always check for hidden wires or pipes, etc.



## Tips & Tricks


**Make sure that the hardware used is suitable for supporting your unit.**

**Please consult a qualified tradesperson if unsure.**

- ☑ If you are unsure, please select a larger screw and wall plug.
- ☑ Ensure that you use the recommended drill bit to match the wall plug and hole size.
- ☑ Take extra care when drilling high walls, ceiling and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid splitting or cracking.
- ☑ Ensure that wall plugs are well fitted and are a tight fit in the drilled hole.


## Types of Walls

Use one of the following types of wall plug (not included) if your walls are made of brick, breeze block, concrete, stone or wood. Screws may be able to be fixed directly to solid wood walls as they will provide a secure anchor point.




### 1. General Purpose Wall Plug

Generally, aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




### 2. Plasterboard Wall Plug

For use when attaching light loads onto plasterboard partitions.




### 3. Cavity Fixing Wall Plug

For use with plasterboard partitions or hollow wooden doors.




### 4. Cavity Fixing Heavy Duty Wall Plug

For use when fitting or supporting heavy loads such as shelving and wall cabinets.



### 5. Hammer Fixing Wall Plug

For use with concrete block or brick walls, or walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



### 6. Shield Anchor Wall Plug Heavy Loads

For use with concrete or brick walls, or for use with heavier loads such as TV & HiFi speakers and satellite dishes, etc.