


Read these instructions and follow steps carefully to ensure you assemble the product correctly and avoid damages. Check that all parts hardware have been provided before assembling the products. Place all contents on a clean, soft-flat surface to avoid scratching the product.

CAUTION:


Only tighten bolts to 80% at first. Once all parts have been assembled, fully tighten all hardware. To prevent damage to threads, do not use a power tool and do not over tighten bolts.























Use two people to lift and turn the product when assembling.

Do not attempt with only one person and do not roll on to legs. Keep all hardware and small parts away from children.




Do not stand on the product




A  6 PCS	B  6 PCS	C  13 PCS	D  13 PCS	E  10 PCS	F  1 PC	G  1 PC	H  1 PC
I  1 PC	J  2 PCS	K  4 PCS	L  10 PCS	M  10 PCS	N  10 PCS	O  1 PC	P  1 PC
Q  1 PC	R  1 PC	S  2 PCS	T  2 PCS	U  5 PCS	V  2 PCS		

Step 1:




Attach 1 x CL & CR Runner Track (F,G) to Left & Right Side Panel (2 & 3) with 6 x Small Screws (E). Tighten with a Phillips Head Screwdriver. Attach 4 x Cam Bolts (C) to Left & Right Side Panel (2 & 3) as shown. Tighten with a Phillips Head Screwdriver.

Step 2:




Attach 2 x Rails (8) to Panel (6) with 6 x screws (B). Tighten with a Phillips Head Screwdriver.

Step 3:




Insert 1 x Dowel (A) into Rail (7). Push 5 x Bolts (M) through Left Side Panel (2) and insert 5 x Nuts (N) and 2 x Cam Nuts (D) into Shelf Panel (4), Rails (7 & 8) and Back Panel (5). Rotate the nuts so the opening point towards the incoming bolts. Attach Left Side Panel (2) to Shelf Panel (4), Rails (7 & 8) and Back Panel (5) by tightening all nuts with the Phillips Head Screwdriver.

Step 4:




Insert 1 x Dowels (A) into Rail (7). Push 5 x Bolts (M) through Right Side Panel (3) and insert 5 x Nuts (N) and 2 x Cam Nuts (D) into Shelf Panel (4), Rails (7 & 8) and Back Panel (5). Rotate the nuts so the opening point towards the incoming bolts. Attach Right Side Panel (3) to Shelf Panel (4), Rails (7 & 8) and Back Panel (5) by tightening all nuts with the Phillips Head Screwdriver.

Step 5:




Attach 6 x Cam Bolts (C) to Top Panel (1) as shown. Tighten with a Phillips Head Screwdriver.

Step 6:




Insert 4 x Dowels (A) and 6 x Cam Nuts (D) into the holes of Left & Right Side Panels (2 & 3) and Back Panel (5). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (1) into place and tighten the cam nuts.

Step 7:




Attach 3 x Cam Bolts (C) to Drawer Front (9) as shown. Tighten with a Phillips Head Screwdriver.

Step 8:




Attach Drawer Back (12) to Left & Right Drawer Side (10 & 11) with 5 x Screws (U) by tightening with the Phillips Head Screwdriver.

Step 9:



Slide Drawer Base (13) into the grooves of Left & Right Drawer Side (10 & 11).


Step 10:



Insert 2 x Small Dowels (V) into Left & Right Drawer Side (10 & 11).


Insert 3 x Cam Nuts (D) into Left & Right Drawer Side (10 & 11) and Rail (14). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Drawer Front (9) to Left & Right Drawer Side (10 & 11). Make sure that the groove lines up the whole way around the drawer. Tighten with a Phillips Head Screwdriver.

Step 11:




Attach 1 x DL Runner (H) to the bottom of Left Drawer Side (10) and 1 x DR Runner (I) to the bottom of Right Drawer Side (11) with 4 x Small Screws (E) by tightening with the Phillips Head Screwdriver.

Step 12:




Attach 2 x Handles (J) to Drawer Front (9) with 2 x Handle Bolts (K) or 2 x Handles (T) to Drawer Front (9) with 2 x Handle Bolts (K) as shown. Tighten with the Phillips Head Screwdriver.

Step 13:




Insert the assembled drawer into the corresponding compartments as shown.

Step 14:




Attach 10 x Hole Stickers (L) to Side Panels (2 & 3) as shown.

Step 15:



Attach 1 x safety strap (O) to the Back panel (5) as shown using 1 x washer (S) and 1 x screw (P). Tighten with the Phillips Head Screwdriver.

Step 16:



Move the unit to the final position. Fasten the safety strap to your wall using appropriate fixings for your wall type. If you are unsure, please seek professional advice on how to attach this safety strap to your specific wall.



WARNING

It is STRONGLY RECOMMENDED that you ANCHOR this product.

Toppling furniture can cause serious injuries and death.

This product has been provided with an anchor strap. To prevent your furniture from tipping forward it is strongly recommended that you securely attach this product to a wall or other solid surface, using the anchor strap provided and appropriate fixings.

IMPORTANT:

Regularly check that anchors are securely maintained.

Stability of tall items may be affected by thick pile carpet or uneven floors.

CAUTION:

- For your safety when attaching the anchor fixings, please note the following:
Check for any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson)
- Walls are constructed from different materials, for example, masonry (solid brick) or plasterboard lined cavity walls (hollow). It is important that you use the appropriate wall fixings for your wall type.
- Your local hardware store will have the necessary drills and fixings and can offer advice if needed. If in doubt, engage the services of a qualified tradesperson to install and anchor the product.