


ASSEMBLY INSTRUCTIONS

GEORGIA NATURAL BOOKSHELF



Two people required

www.templeandwebster.com.au

Keep these instructions for future reference

Assemble the furniture on a soft level surface to avoid damaging the furniture or your floor.

Parts of the assembly will be easier with 2 people.

We recommend furniture be assembled near where they will be placed, to avoid moving the product unnecessarily once assembled.

If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.

Regularly check and re-tighten (if necessary) all bolts on furniture that you have assembled yourself.


Warning: In order to prevent overturning, this product must be used with the wall attachment device provided.

Do not stand on the Furniture


Care and Maintenance of your Furniture

Wipe clean with a damp cloth. Use only water or a gentle detergent.
Wipe dry with a clean cloth.


Tools Required




DO NOT USE




Mallet



Flat head Screwdriver



Cross Screwdriver




60 min

Time Required


Part List

- 1 Main Panel
- 2 Pillar
- 3 Side Panel
- 4 Small Support Panel
- 5 Large Support Panel

people Required




Hardware/Fittings



Ø15x12 mm Cam Lock x 10

A



Ø7.5x32 mm Cam Bolt x 10

B




Ø17 mm Cam Cap x 10

C



Ø8x32 mm Plastic Dowel x 60

D



Ø6.3x50 mm Screw x 40

E




Ø12 mm Cam Shock x 40

F




Ø3x12 mm Screw x 1

G



Anti-tip Bracket x 1


H



Allen Key x 1


I

1



Screw 10 x Cam Bolts (B) into Main Panel (1).
Insert 60 x Plastic Dowels (D) into main Panel (1) Small Support Panel (4) and Large Support Panel (5),
If necessary, gently tap the Plastic dowels with a mallet.

2




Attach Small Support Panel (4) to Large Support Panel (5) using 5 x Screws (E),
Use Allen Key (I) to turn the Screws clockwise to lock.
Paste 5 x Cam Shock (F) as shown.


3



Ax10




Cx10



Attach Assembly (4 and 5) to Top Panel (1) using 10 x Cam lock (A) as shown,
Use a screwdriver to turn the Cam lock clockwise to lock.
Paste 10 x Cam Sticker (C) as shown.

X5


4



Ex10





Fx10



Attach 1 x Pillar (2) to Assembly using 10 x Screws (E),
Use Allen Key (I) to turn the Screws clockwise to lock.
Paste 10 x Cam Shock (F) as shown.



6

5



Attach Side Panel (3) to Assembly using 15 x Screws (E),
Use Allen Key (I) to turn the Screws clockwise to lock.
Paste 15 x Cam Shock (F) as shown.

6



Attach 1 x Pillar (2) to Assembly using 10 x Screws (E),
Use Allen Key (I) to turn the Screws clockwise to lock.
Paste 10 x Cam Shock (F) as shown.


7




Gx1



Hx1



OPTION 1




OPTION 2

Attach Anti-tip Bracket (H) to Pillar (2) or Side panel (3) using 1 x Screws (G).

8

8


OPTION 1



Screw Anti-tip Bracket on the wall after assembling complete as shown.


9

OPTION 2



Screw Anti-tip Bracket on the wall after assembling complete as shown.

10



Assembly is complete.

**Please dispose of all
packaging thoughtfully**