

# ASSEMBLY INSTRUCTIONS












PAGE: 1/5



MODEL : KADEN BUFFET

Before you begin, please follow assembly instructions carefully, then follow them step by step.

Read instruction carefully . See Furniture Parts list and Hardware List for guidance . Be sure you have all parts before you start assembling .  
Place and assemble furniture on a clean flat soft surface , such as carpet or rug to prevent being scratched .

PART LIST		QTY
1	TOP PANEL	1 PC
2	BOTTOM PANEL	1 PC
3	SIDE PANEL (L)	1 PC
4	SIDE PANEL (R)	1 PC
5	CENTER PANEL (L)	1 PC
6	CENTER PANEL (R)	1 PC
7	MIDDLE BONE (L/R)	2 PCS
8	MIDDLE BONE (C)	1 PC
9	CABINET LEG	1 PC
10	CENTER LEG	2 PCS
11	BACK PANEL	1 PC
12	SHELF PANEL (L/R)	2 PCS
13	SHELF PANEL (C)	1 PC
14	DOOR PANEL (L)	1 PC
15	DOOR PANEL (C)	1 PC
16	DOOR PANEL (R)	1 PC

HARDWARE					
A	MINI FIX	A1  A2  A3 		20 SETS	
B	M8 X 30MM WOOD DOWEL			34 PCS	
C	M6 X 50MM CSK CAP WOOD SCREW			4 PCS	
D	ALLEN KEY M4			1 PC	
E	M3.5 X 16MM C.B SCREW			36 PCS	
F	5/8 NAIL			30 PCS	
G	5/8 PVC NAIL LEG			8 PCS	
H	METAL SHELF SUPPORT			12 PCS	
I	SOFT CLOSING 5/8 HINGES			6 PCS	



**SELF-PREPARED TOOLS:** Tools below are NOT included in package.



SCREWDRIVER



HAMMER

## Reminder:


Please ensure that all surfaces and edges with colours/laminations are facing forward/outward.

# ASSEMBLY INSTRUCTIONS

PAGE: 2/5

## STEP 1


- Insert hardware **A1** onto panel **(2)**.  
(Repeat 4 times.)
- Insert hardware **A2** onto panel **(1), (2)** and **(9)**.  
(Repeat 16 times.)
- Insert hardware **B** onto panel **(2)**.  
(Repeat 4 times.)



\* Ensure the arrows on hardware **A1** point towards mounting positions.

## STEP 3

- Insert hardware **A1** onto panel **(3)** and **(4)**.  
(Repeat 6 times.)
- Insert hardware **A2** onto panel **(3)** and **(4)**.  
(Repeat 4 times.)
- Insert hardware **B** onto panel **(3)** and **(4)**.  
(Repeat 6 times.)




\* Ensure the arrows on hardware **A1** point towards mounting positions.

# MODEL : KADEN BUFFET

## STEP 2


- Insert hardware **A1** onto panel **(10)**.  
(Repeat 6 times.)
- Insert hardware **B** onto panel **(7), (8)** and **(10)**.  
(Repeat 16 times.)



\* Ensure the arrows on hardware **A1** point towards mounting positions.

## STEP 4

- Insert hardware **A1** onto panel **(5)** and **(6)**.  
(Repeat 4 times.)
- Insert hardware **B** onto panel **(5)** and **(6)**.  
(Repeat 8 times.)



\* Ensure the arrows on hardware **A1** point towards mounting positions.


# ASSEMBLY INSTRUCTIONS

PAGE: 3/5

# MODEL : KADEN BUFFET

## STEP 5


- Attach panel (8) to panel (5) and (6).



\* In this step hardware A1, A2 and B are pre-inserted.

## STEP 7



- Attach panel (10) to panel (2).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 4 times.)



\* In this step hardware A1, A2 and B are pre-inserted.

## STEP 6


- Connect panel (2) to panel (5) and (6) by using hardware C and D.
- (Repeat 4 times.)



\* In this step hardware B are pre-inserted.

## STEP 8

- Attach panel (7) to panel (5) and (6).
- Attach panel (3) and (4) to panel (2) and (7).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 4 times.)



\* In this step hardware A1, A2 and B are pre-inserted.

# ASSEMBLY INSTRUCTIONS


PAGE: 4/5

## STEP 9

- Attach panel (9) to panel (3), (4) and (10).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 4 times.)




OR



\* In this step hardware A1, A2 and B are pre-inserted.

## STEP 11

- Assemble panel (11) to entire body with hardware F.
- (Repeat 30 times.)




# MODEL : KADEN BUFFET

## STEP 10

- Attach panel (1) to panel (3), (4), (5) and (6).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 8 times.)




OR



\* In this step hardware A1, A2 and B are pre-inserted.

## STEP 12

- Hit hardware G into bottom of panel (3), (4) and (10).
- (Repeat 8 times.)




# ASSEMBLY INSTRUCTIONS

PAGE: 5/5


## STEP 13

- Insert hardware **H** into mounting positions on panel **(3)**, **(4)**, **(5)** and **(6)** by hand.  
(Repeat 12 times.)



## STEP 15


- Fix hardware **I** onto panel **(14)**, **(15)** and **(16)** by using hardware **E**.  
(Repeat 2 times for each hardware.)



# MODEL : KADEN BUFFET

## STEP 14


- Assemble panel **(12)** into between panel **(3)** & **(5)** then **(4)** & **(6)**.  
(Repeat 2 times.)
- Assemble panel **(13)** into between panel **(5)** and **(6)**.  
(Repeat 1 times.)



- \*In this step hardware **H** are pre-inserted.
- \*Hardware **H** can fix to another up and down hole on panel **(3)**, **(4)**, **(5)** and **(6)** for adjust panel **(12)** and **(13)** to high or lower.

## STEP 16

- Fix hardware **I** into panel **(3)**, **(4)** and **(6)** by using hardware **E**.  
(Repeat 4 times for each hardware.)
- Tighten or loosen the screw to adjust position of panel **(14)**, **(15)** and **(16)**.  
(Do only when needed.)



- \* In this step hardware **I** have been assembled in panel **(14)**, **(15)** and **(16)**.